

FOOT-REST


The footrest can be adjusted to provide you the best possible comfort.




1. You can adjust the height of the strap as shown in the following picture. There are a total of three positions for the strap. Each position can have a small adjustment by adjusting the cap screw in the oval hole.




2. You can adjust the height of the footrest to three positions as shown in the following picture.



3. Each one of the previous positions can be rotated to a total of four positions (picture below).



4. You can release the bottom part of the footrest and connect it to the metal support as shown in the following picture. Please note that you have to unscrew the bottom part of the footrest for connecting it with the metal support.



If you want to use the full footrest, you can use the metal support for supporting the lower part of the footrest and providing more stiffness. Please note that in this case the two cap screws that connect the metal support to the lower part of the footrest have to be unscrewed.


5. The carbon strap can be replaced with a neoprene strap (picture below).



6. You can also change the neoprene strap to a lower position as shown in the following picture.



7. The carbon strap can also be replaced by a carbon pull bar. Additionally the carbon pull bar can be used in the same three positions as the carbon strap (picture below).



8. The footrest can be used in a smaller configuration (without the bottom part) as shown in the following picture.

